



Medical waste crushing and high temperature sterilization machine

process flow

1. Medical personnel classify medical waste according to the "Medical Waste Classification Catalog".
2. According to the category of medical waste, medical waste should be placed in a special packaging bag or container, and the packaging bag or container should comply with the provisions of the "Special Packaging Container Standards and Warning Signs for Medical Waste".
3. Before loading medical waste, medical personnel should carefully inspect the packaging or container to confirm that there are no damage, leakage and other defects.
4. When the medical waste reaches 3/4 of the package or container, an effective sealing method should be adopted to make the seal tight.
5. On the outside of each package or container containing medical waste, warning signs and Chinese labels should be affixed on its surface, including the unit, date and category of medical waste.
6. Infectious waste, pathological waste and destructive waste packed into packages or containers shall not be taken out at will.

7. Professional medical waste management personnel transport classified and packaged medical waste from the place where medical waste is generated to the temporary storage room of the hospital according to the prescribed route every day; during the transportation process, the loss and leakage of medical waste should be prevented, and direct contact with medical waste should be prevented human body. After the daily transportation work is completed, the transportation tools shall be cleaned and disinfected in time.

8. Full-time medical waste management personnel shall weigh and register the medical waste at the place of production every day. The registration content includes source, type, weight, handover time, final destination, handler, etc.

9. The medical waste in the temporary storage room shall be handed over by full-time personnel to the county health bureau and the county environmental protection bureau to designate special personnel for disposal. The storage time shall not exceed two days, and the "Hazardous Waste Transfer Form" shall be filled out.

10. After the medical waste is transferred out, full-time personnel should clean up and disinfect the temporary storage places and facilities in time, and make records.

11. Unqualified rural medical institutions can be destroyed and incinerated after soaking in 1:50 84 disinfectant for 6 hours.

Solution

1. According to the "Urban Medical Waste Treatment Measures".

2. Register in detail the amount of medical waste stored.

3. All kinds of medical wastes are classified and stored.

4. Clean and disinfect the storage facilities in time.

5. Send the medical waste to the designated unit for recycling every two days, fill in the "Hazardous Waste Transfer Form" and "Medical Waste Transportation Registration Card", and sign.

Keep various records.